1 Generator (GEN) warning lamp does not light up when ignition is switched on.

1.1 Generator (GEN) warning lamp does not light up when ignition is switched on.

1.1.1 Test conditions:

- Belt tension and battery voltage OK.
- Ground connections (between engine, body and battery) and generator (GEN) connections must be tight and clean (free of corrosion/oxidation).

Check wire between generator (D+) and warning lamp	
- Disconnect D+ wire from generator. - Short to ground. - Switch ignition ON.	
Lamp does not light up	Lamp lights up

Check wire according to wiring diagram and check warning lamp in instrument cluster.

- Switch ignition OFF. - Remove voltage regulator. - Check brushes, ⇒ Rep. Group 27	
Brushes NOT OK	Brushes OK

Replace brushes or voltage regulator.

Replace generator, ⇒ Rep. Group 27

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Volkswagen AG. Volkswagen AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by Volkswagen AG.